






CARBON FIBER
PORSCHE - FERRARI - LAMBORGHINI

996 Instrument Surround Installation Guide




Tools Required

MAcarbon Interior Install Tools	
T-20 Torx wrench	
Soft Cloth	



CARBON FIBER
PORSCHE - FERRARI - LAMBORGHINI

Installation Steps

Step	Instructions	Photo
1	Use the MCarbon install tools to gently pry off the hazard surround and the sensor cap on the left of the gauges.	
2	Use the T-20 Torx to take out the two screws behind the sensor cap, and hazard button.	
3	Gently pull the whole dash pod up. The rear is held on to the dash with clips, and the pod needs to be un-snapped from the dash by pulling up.	
4	You will see three plugs on at the back of the pod. These clips are disconnected by pushing the clip in the center inward and pulling the black lever up. It will unhook the plug off its track. Do this for all three.	
5	Next you will disconnect the hazard switch. Gently pry the switch and pull it through the dash. The whole dash pod will free from the dash completely.	
6	With the pod out of the car, place the pod on your workbench on top of the soft cloth. Remove the Torx screws on the back and free the instrument surround.	
7	Take advantage of the dash pod being out to clean the areas of the dash that are usually difficult to reach.	
8	Install is reverse, just remember to snap the rear of the pod before screwing it in.	