



Custom Made Carbon for Exotics

Ferrari 430, 458, 599, California Manettino Sticker Installation Instructions

Installation Statistics

Ease of Install	Hobbyist
Time to Install	45 minutes

Tools Required

<p>2MM Allen wrench Blue Painters Tape Cloth ‘Goo Gone’ or other adhesive remover Scissors Small Knife</p>	
---	--

NOTE: All photos show the sticker being installed with the wheel out of the car and disassembled. REMOVING THE WHEEL IS NOT NECESSARY. This is done for clarity only.

Installation Steps

Step	Instructions	Photo
1.	<p>Use the 2MM Allen to loosen the jam screw on the manettino knob.</p> <p>NOTE: DO NOT remove the wheel or disassemble it. The photos show this for clarity.</p>	







Custom Made Carbon for Exotics

Step	Instructions	Photo
2.	Mask off the silver (or carbon) wheel center. Use the knife to cut the sticker around the manettino switch. Begin to peel the sticker from the panel.	
3.	Continue to pull the sticker from the panel.	
4.	Even after the sticker is removed, the original adhesive will still be present.	
5.	Apply the adhesive remover to the cloth. Wipe the panel down to remove the old adhesive. Do not apply too much liquid as you do not want that getting into the manettino electronics.	





Custom Made Carbon for Exotics

Step	Instructions	Photo
6.	This photo shows the panel and a glob of adhesive after cleaning.	
7.	Trim the backing until its close to the sticker edge.	
8.	Practice inserting the sticker into the recess. Do not remove the backing. The sticker is VERY sticky. So take a few moments to practice.	
9.	Wipe down the panel with the adhesive promoter.	



Custom Made Carbon for Exotics

Step	Instructions	Photo
10.	Now apply the sticker to the panel. Make sure the sticker is straight. Press down when you have the correct alignment. If you do not press it, you can move it slightly using the knife.	
11.	Reattach the knob.	
12.	Enjoy your handiwork!	